纸张：100G书纸
印刷：双面印刷
折页方式：骑马钉
尺寸：81*110mm

封底

封面

Health and Safety Information
Please read and observe the health and safety information. Failure to do so could result in:
• Battery leakage: Adults should supervise the use of this product by children.

WARNING 1- Electrical Safety
• Do not expose this product to microwaves, high temperatures or direct sunlight.
• Do not flush this product; some components may contain metal and could cause electrical hazards.
• Do not expose this product to excessive force. Do not pull on the USB cable with excessive force or bend it.
• Do not touch this product while charging during a thunderstorm.
• Stop using the charger if you see smoke or smell something strange.
• Stop using the charger if you see smoke or smell something strange.
• Do not disassemble or try to repair this product if this product is damaged. Do not touch damaged areas. Avoid contact with any leaking fluid.

WARNING 2- General
• Keep small parts, especially parts away from young children as they may choke on them. Only use the USB charging cable can fall around the neck.

CAREFUL USAGE
• If this product becomes dirty, wipe it with a soft, dry cloth. Avoid using thinner or other solvents.

Key Function



For N-S/Lite + Wireless Mode
Steps:
① In the N-S/Lite main menu, click on Controller->Change grip/sequence, and enter the Controller pairing mode.

② Press and hold the ⓖ "Pairing" or 🔗"+" ⓑ HOME button for 2-3 seconds to enter the pairing mode. The LED flash frequency. After the connection is successful, the LED been on.

Pairing Status ——— ● ● ● ——— Connection Successful ——— ● ● ●

③ When the connection is successful, you can press the ⓐ HOME button, and the LED will flash slowly in the form of a marquee and automatically reconnect.

For N-S/Lite + Wired Mode
1. Use the USB cable to connect to the Type-C port of the controller and the USB port of the host, and the corresponding LED light of the controller will flash slowly.

2. When the controller is connected to the base of S-switch through the USB cable, the LED flashes in the form of a marquee, and the corresponding LED light of the controller will flash slowly.

Connection Successful ——— ● ● ●

3. Unplug the USB cable, the controller turns into the wireless mode, and automatically reconnects to the console.

For PC + Wired Mode
1. Connect the controller to the computer with the USB cable. The LED flashes in the form of a marquee, and the LED is on at the same time, and then it is successfully connected.

Pairing Status ——— ● ● ● ——— Connection Successful ——— ● ● ●

2. The controller defaults to Input mode（computer mode）on the PC side, and the keys are not XB 360 key Layout.

• Input mode switching does not need to be set on the game platform.

3. Press and hold the HOME button for 3s, it can be converted from Input to the Direct Mode（PC/360 mode）. LED and LED1 been on at the same time.

• "Direct" needs to set a custom button

Switch Successfully ——— ● ● ●

Note: You could play PC games on Steam, Not all PC games are compatible with the controller, please confirm that the game supports the controller before use.

For PC + Blue-tooth Mode
1. Press the ⓐ + ⓑ HOME button for 2-3 SECONDS at the same time to turn on the controller (To prevent accidental touch, it is recommended to press and hold the ⓐ + ⓑ HOME button for 2-3 seconds at the same time to press the HOME button, and ensure that the two buttons are pressed and held at the same time for more than 3 seconds).

2. When the LED and LED3 flash frequently, the controller enters the search mode.

Search Mode ——— ● ● ●

3. Turn on the Blue-tooth of phone, enter the search mode, and click on the device to search for the controller of Gamepad to connect.

4. After successfully connected, LED2 and LED3 been on, which means the controller can be used normally.

Connection Successful ——— ● ● ●

Note: The Blue-tooth connection is unstable, and it is recommended to use the wired mode for PC games.

For IOS + Blue-tooth Mode
1. Press the ⓐ + ⓑ HOME button at the same time to turn on the controller (To prevent accidental touch, it is recommended to press and hold the ⓐ + ⓑ HOME button for 2-3 seconds at the same time to press the HOME button, and ensure that the two buttons are pressed and held at the same time for more than 3 seconds).

2. When the LED and LED3 flash frequently, the controller enters the search mode.

Search Mode ——— ● ● ●

3. Turn on the Blue-tooth of phone, enter the search mode, and click on the device to search for the controller of N-S wireless controller to connect.

4. After successfully connected, LED2 and LED3 been on, which means the controller can be used normally.

Connection Successful ——— ● ● ●

Note: The Blue-tooth connection is unstable, and it is recommended to use the wired mode for IOS games.

For Android + Blue-tooth Mode
1. Press the ⓐ + ⓑ HOME buttons at the same time to turn on the controller (To prevent accidental touch, it is recommended to press and hold the ⓐ + ⓑ button first and then press the ⓐ HOME button, and ensure that the two buttons are pressed and held at the same time for more than 3 seconds).

2. When the LED and LED3 flash frequently, the controller enters the search mode.

Search Mode ——— ● ● ●

3. Turn on the Blue-tooth of phone, enter the search mode, and click on the device to search for the controller of N-S wireless controller to connect.

4. After successfully connected, LED2 and LED3 been on, which means the controller can be used normally.

Connection Successful ——— ● ● ●

Note: Not all PC games are compatible with controller, please confirm that the game supports controller before use.

About TURBO Function
There are 3 burst speeds and auto speeds(S shot/s, D shot/s, 25 shot/s).Default for first connection 12 shot/s.

S shot/s, The HOME light flashes in a moderate manner (slowly flash for 2 time per second).

D shot/s, The HOME light flashes frequently. (slowly flash for 4 times per second).

25 shot/s The HOME light flashes frequently. (slowly flash for 4 times per second).

2 types of bursts: manual burst and auto burst

1. Manual burst: Press and hold the ⓡ2 button, and then press the ⓨ button one of the function buttons to turn on the manual burst.

2. Open auto burst: Press and hold the ⓡ2 button, and then press and hold the button that has turned on the manual burst to turn on auto burst. (Auto burst can be paused).

3. Clear burst: Press and hold the ⓡ2 button, and then press and hold the button that has turned on the auto burst to turn off the current button with burst function.

4. Clear all burst button burst: Press and hold the ⓡ2 button and the ⓨ "Down" arrow on the D-pad. Once the controller vibrates, the burst function of all buttons is cleared.

Adjust the burst speed:

1.How to increase the burst speed?
Press and hold the ⓡ2 button and the △ "up" arrow on the D-pad. Once the controller vibrates, the burst speed is successfully increased.

2.How to reduce burst speed?
Press and hold the ⓡ2 button and the ▽ "Down" arrow on the D-pad. Once the controller vibrates, the burst speed is successfully reduced.

Snow to set the duration when adjusting the burst speed?

Press the ⓡ2 button and press the △ button/▽ "Down" arrow on the D-pad at the same time. Once the controller vibrates, the command is successfully set.

6. Will the burst setting be lost when the controller is disconnected. The controller will keep the last setting when it is connected.

About Vibration

There are 4 levels settings, is total: weak, none, medium, strong (Default strong, 0,33%, 66%, 100%).

How to set up the vibration?

Press the vibration ⓥ adjustment button at the back of the controller, and the controller will vibrate in 4 speeds in sequence.

Which speed is the default for the first connection?

Default strong (100%) vibration.

How to set the vibration to be turned off?

Set via the Mapping Mode.

M1 or M2 + "-": Only one button value can be mapped to the back button under the Mapping Mode.

M1 or M2 + "-": You can define up to 16 button values to the back buttons in macro definition mode.

* The default M1 and M2 have no button function value.

How to map one button to M1 or M2 key?

1.Press and hold M1 or M2 + "-" at the same time for 2-3 seconds. The LED flash frequency, and the RGB lights of the left and right joysticks turn white and flash slowly, indicating that it enters the programming mode.

2.Press a macro button button (A/B/X/Y/L1/L2/R1/R2/M1/M2) to be mapped, and the RGB lights of the left and right joysticks flash from slowly to fast, indicating that the function button to be mapped have been selected.

Example:
To map the four button values of A+B+X+Y to M1 key: press M1 + "-" at the same time for 2-3 seconds. Once the controller vibrates, the RGB lights of the left and right joysticks turn white and flash slowly, which means the controller already the mapping mode. Press the A, B, X, Y, buttons in turn, and then press the M1 key, the RGB lights of the joystick flash slowly to frequently, Press M1 to confirm, and the controller vibrates twice, indicating that the setting is successful.

How to clear the M1/M2 function that has been set?
Press "+" + buttons for 2 seconds. Once the controller vibrates, the setting is cleared and M1/M2 has no button function value added

About Joystick/ LED Adjustment Button.
Lighting effect of the joystick does are 6 colors x rainbow LED light for different light modes. You can change the style you like with the LED button.

Static Mode
Press the ⓡ3 "LED" button to enter static mode. The joysticks will keep the last color of the joystick when it is off. For example, the joystick takes on a different color. Green->red->orange-yel low-green-blue->purn-purple->blue->off)

Strobe Mode
Press the ⓡ3 "LED" and ⓡ1 "+" button at the same time, the LEDs flash slowly, which means the controller enters the Strobe Mode. Press the ⓡ3 "LED" button to exit the light mode.

Breathing Mode
Press the ⓡ3 "LED" and ⓡ1 "+" button for the third time to enter Breathing Mode. The RGB colors of the joysticks will automatically cycled slowly one by one.

How to turn off the lights?
Press and hold the ⓡ3 "LED" button and the Left Joystick to turn off the lights and repeat the above operations to turn the light back on.

How to increase the brightness of the light?
Press and hold the ⓡ3 "LED" button and the left joystick up. (25%->50%->75%->100%)

How to reduce the brightness of the light?
Press and hold the ⓡ3 "LED" button and the left joystick down.

Will the brightness setting be saved?
Yes, the setting will be saved when the controller is disconnected. The controller will keep the last setting when it is connected. Brightness defaults to 75%.

About Gyroscope Sensor Calibration
Press the ⓡ3 "LED" and ⓡ2 "-" button at the same time. (Press the ⓡ3 " button, then press the ⓡ3 "HOME" button) LED1 LED2 LED3 LED4 turn on.
Press the ⓡ3 " button at the time LED LED1 LED2 LED3 LED4 turn on once and off at the same time, indicating that the calibration is successful.

Solutions for controller disconnection
The reason for this may be that the controller is out of power, and

you can try to charge it.
2.Clear the handle information in the N-Switch console;

3.Changing to a wired connection.
4.Check whether the handle is blocked or interfered with by obstacles. You can try again elsewhere or at other times.

Solutions For Drift
If the controller drifts, you need to calibrate the controller. Steps: Click "Settings", click "Controller and Sensors", and click "Calibrate Control Sticks".

Solutions For Controller Getting Stuck
If the controller gets stuck, you may need to move the joystick to the center and press it down gently.

About Reset The Controller
Press and hold the ⓐ HOME button for 6s to shut down for reset or press the reset button at the back

Factory Reset
Press and hold the Home and right joystick at the same time, and press the ⓐ HOME button for 6s. The EU/ LEDs turn on once and off, and the setting gets restored.
Press and hold the ⓐ HOME button for 6s to force the shutdown.

Gesundheit- und Sicherheitshinweise
Bitte lesen und beachten Sie die Gesundheits- und Sicherheitsinformationen. Eine Nichtbeachtung kann zu Verletzungen oder Schäden führen. Dies kann beispielsweise auf verschiedene Arten passieren:
Auslaufen der Batterie:

WARNUNG 1 - Elektrische Sicherheit
• Setzen Sie dieses Produkt keiner Mikrowellen, hohen Temperaturen oder direkter Sonneinstrahlung aus.
• Spülen Sie dieses Produkt nicht mit Flüssigkeit in Berührung kommen und verwenden Sie es
nicht mit nassen oder klaren Händen. Wenn Flüssigkeit in das Innere eindringt, trocknen Sie es vollständig ab, bevor Sie es wieder verwenden.
• Setzen Sie dieses Produkt nicht übermäßiger Kraft aus. Ziehen Sie nicht zu fest am USB-Kabel.
• Berühren Sie dieses Produkt nicht während eines Gewitters.
• Wenn Sie Rauch sehen oder riechen, hören Sie sofort mit dem Aufladen Geräusch oder einen ungewöhnlichen Geruch wahrnehmen, stoppen Sie das Aufladen.
• Versuchen Sie nicht, dieses Produkt auseinander und versuchen Sie nicht, es zu reparieren.
• Wenn dieses Produkt beschädigt ist, berühren Sie es nicht. Vermeiden Sie Kontakt mit auslaufender Flüssigkeit.

WARNUNG - Allgemein
• Halten Sie Kleinteile, insbesondere von kleinen Kindern fern, da es kann, das USB-Ladekabel kann sich um den Hals wickeln

VORSICHTIGER GEBRAUCH
• Wenn dieses Produkt verschmutzt ist, wischen Sie es mit einem weichen, trockenen Tuch ab. Vermeiden Sie die Verwendung von Verdünner oder anderen Lösungsmitteln.

Schüsselfunktion

Für N-S/Lite Wireless Mode Zwei Möglichkeiten der Verbindung:
Schritte:
① In the N-S/Lite main menu, click on Controller->Change grip/sequence, and enter the Controller pairing mode.

② Halten Sie die Taste ⓖ"Pairing" oder 🔗"+" ⓑ HOME für 2-3 SECONDS gedrückt, um in den Kopplungsmodus zu gelangen. Die LED-Blinkfrequenz wechselt, und das entsprechende LED-Licht des Controllers bleibt langsam.

Pairing Status ——— ● ● ● ——— Connection successful ——— ● ● ●

③ Wenn die Verbindung erfolgreich ist, können Sie die ⓐ HOME-Taste drücken, und die LED blinkt langsam in Form einer Laufschrift und verbindet sich automatisch neu.

④ Press the ⓐ HOME key to wake up the console.

Hinweis: Wenn die Konsole schwarz ist, den Controller zu kopplik, kann es sein dass der Controller sich im Ruhezustand befindet. Drücken Sie eine beliebige Taste, um den Controller zu aktivieren.

Für N-S/Lite im kabelgebundenen Modus:
1. Wenn Sie ein kabelgebundenes Verbindung verwenden, vergewissern Sie sich, dass die kabelgebundene Pro-Controller verbindung in den Systemeinstellungen der N-Switch-Konsole aktiviert ist.

2. Der Controller ist standardmäßig auf Input-Modus (Computermodus) auf der PC-Seite eingestellt, und die Tasten sind nicht XB0-Tastenlayout.

• Input-Modus kann zwischen Input und Direct umgeschaltet werden, ohne dass die Spieleinstellungen auf der Spieleplattform vorgenommen werden müssen.

3. Halten Sie die HOME-Taste für 3s, es kann von Input in den Direct-Modus（PC/360-Modus）umgewandelt werden. LED und LED1 waren gleichzeitig eingeschaltet.

• "Input" muss benutzerdefinierte Schaltflächen festlegen

Über die somatosensorische Kalibrierung
Drücken Sie die Taste ⓡ3 " und halten Sie gleichzeitig die Taste ⓡ2 "-" gedrückt (Drücken Sie zuerst die Taste ⓡ3 " und dann die Taste ⓡ3 "HOME"). LED1 LED2 LED3 LED4 schalten sich ein.
Drücken Sie die Taste ⓡ3 " zu diesem Zeitpunkt schalten sich LED1 LED2 LED3 und LED4 gleichzeitig aus, um anzuzeigen, dass die Kalibrierung erfolgreich ist.

Lösungen für die Controller-Trennung
Der Grund dafür kann sein, dass der Controller keinen Strom mehr hat und die verschiedenen Methoden zum Aufladen.
2. Überprüfen Sie, ob das Gerät in einem dunklen Bereich schattiert ist.

3. Wechseln zu einer kabelgebundenen Verbindung.
4. Überprüfen Sie, ob das Gerät durch Hindernisse blockiert oder gestört werden. Sie können es an anderer Stelle oder zu anderen Zeiten erneut versuchen.

Lösungen für Drift
Wenn der Controller driftet, müssen Sie den Controller kalibrieren. Schritte: Klicken Sie auf „Einstellungen", klicken Sie auf „Controller und Sensoren" und klicken Sie auf „Steuerknüppel kalibrieren".

Über die LED-Anpassungstaste des Joysticks.
Lichteffekt des Joysticks Es gibt 6 Farben & Regenbogen-LED-Licht für verschiedene
Lichtmodi. Sie können den gewünschten Stil mit der LED-Taste ändern.

Statischer Modus
Drücken Sie die Taste ⓡ3 "LED"-Taste, um in den statischen Modus zu gelangen. Die Joysticks behalten die vor ihrem gewählte Farbe. Sie (Lassen Drücken die „LED" nimmt der Joysticks eine andere Farbe an. Grün->rot->orange->gelb->grün->blau->lila->lila->blau->aus)

Strobe-Modus
Drücken Sie die Tastenkombination ⓡ3 "LED" und ⓡ1 "+" Taste, die LEDs blinken langsam, was bedeutet, dass der Controller in den Strobe-Modus wechselt. Drücken Sie zum Beenden des Lichtmodus die Taste ⓡ3 "LED".

Atmungsmodus
Drücken Sie die(ⓡ3 "LED" - und ⓡ1 "+"- Taste zum dritten Mal, um in den Atmungsmodus zu gelangen. Die RGB-Farben der Joysticks werden automatisch langsam nacheinander durchlaufen.

Wie schalte ich das Licht aus?
Drücken und halten Sie die Taste der Linker Joystick gedrückt, um das Licht auszuschalten, und wiederholen Sie die obigen Vorgänge, um das Licht wieder einzuschalten.

How to increase the brightness of the light?
Press and hold the ⓡ3 "LED" button and the left joystick up.

Wie kann man die Helligkeit des Lichts erhöhen?
Drücken und halten Sie die(ⓡ3 "LED"-Taste und den Linker Joystick nach oben (25 % 50 % 75 % 100 %).

Wie kann man die Helligkeit des Lichts reduzieren?
Halten Sie die(ⓡ3 "LED"-Taste und den Linker Joystick gedrückt.

Lösungen für Controller, die stecken bleiben
Wenn der Controller stecken bleibt, müssen Sie möglicherweise den Joystick in die Mitte bewegen und ihn sanft nach unten drücken.

Über das Zurücksetzen des Controllers
Halten Sie die ⓐ HOME-Taste 6 Sekunden lang gedrückt, um das Gerät zum Ausschalten herunterzufahren, oder Drücken Sie die Reset-Taste auf der Rückseite.

Werkseinstellungen zurücksetzen
Drücken Sie gleichzeitig den Knopf Joystick und den rechten Joystick und die ⓐ HOME-Taste. Die LEDs/EU schalten sich einmal ein und einmal aus, und die Einstellung ist eingestellt/Reset.
Halten Sie die ⓐ HOME-Taste 6 Sekunden lang gedrückt, um das Herunterfahren zu erzwingen.

Lösungen für Controller, die stecken bleiben
Wenn der Controller stecken bleibt, müssen Sie möglicherweise den Joystick in die Mitte bewegen und ihn sanft nach unten drücken.

Über das Zurücksetzen des Controllers
Halten Sie die ⓐ HOME-Taste 6 Sekunden lang gedrückt, um das Gerät zum Ausschalten herunterzufahren, oder Drücken Sie die Reset-Taste auf der Rückseite.

Werkseinstellungen zurücksetzen
Drücken Sie gleichzeitig den Knopf Joystick und den rechten Joystick und die ⓐ HOME-Taste. Die LEDs/EU schalten sich einmal ein und einmal aus, und die Einstellung ist eingestellt/Reset.
Halten Sie die ⓐ HOME-Taste 6 Sekunden lang gedrückt, um das Herunterfahren zu erzwingen.

Wie ordnet man mehrere Tasten der M1- oder M2-Taste zu?

Die RGB-Leuchten des linken und rechten Joysticks werden weiß und blinken langsam, was bedeutet, dass der Controller in den Mapping-Modus wechselt.

Drücken Sie die A-Taste, die Sie zugeordnet werden sollen (mehrfach drücken Sie einen Knopf bis 16 mal).

Drücken Sie zur Bestätigung die M1-Taste.

Und der Controller vibriert einmal, was bedeutet, dass der Tastenwert von M1 jetzt eine A-Taste ist.

abgeschaltet werden soll, und die RGB-Lichter der linken und rechten Joysticks blinken langsam.Drücken Sie nacheinander die Tasten, die zu mappende Funktionstasten ausgewählt wurde.

Beispiel
Um den Wert der Taste A der Taste M zuzuordnen: Drücken Sie M + "-", gleichzeitig für etwa 2-3 Sekunden.

Die RGB-Leuchten des linken und rechten Joysticks werden weiß und blinken langsam, was bedeutet, dass der Controller in den Mapping-Modus wechselt.

Drücken Sie die A-Taste, die Sie zugeordnet werden sollen (mehrfach drücken Sie einen Knopf bis 16 mal).

Drücken Sie zur Bestätigung die M1-Taste.

Und der Controller vibriert einmal, was bedeutet, dass der Tastenwert von M jetzt eine A-Taste ist.

1.Drücken Sie M oder M2 + "-" gleichzeitig für 2-3 Sekunden. Sobald der Controller vibriert, werden die RGB-Leuchten des linken und rechten Joysticks weiß und blinken langsam.
2.Drücken Sie nacheinander die Tasten, die Sie zuordnen möchten (A/B/X/Y/L1/R1/L2/R2/L3/R3/Down/Unten/Entsprechtig), und die RGB-Leuchten des linken und rechten Joysticks blinken langsam.Drücken Sie zur Bestätigung die Taste M, die Sie zuordnen möchten, und der Controller vibriert einmal, was bedeutet, dass der Tastenwert von M + A + B + X ist.

How to clear the M1/M2 function that has been set?
Press "+" + buttons for 2 seconds. Once the controller vibrates, the setting is cleared and M1/M2 has no button function value added

Über die somatosensorische Kalibrierung
Drücken Sie die Taste ⓡ3 " und halten Sie gleichzeitig die Taste ⓡ2 "-" gedrückt (Drücken Sie zuerst die Taste ⓡ3 " und dann die Taste ⓡ3 "HOME"). LED1 LED2 LED3 LED4 schalten sich ein.
Drücken Sie die Taste ⓡ3 " zu diesem Zeitpunkt schalten sich LED1 LED2 LED3 und LED4 gleichzeitig aus, um anzuzeigen, dass die Kalibrierung erfolgreich ist.

Lösungen für die Controller-Trennung
Der Grund dafür kann sein, dass der Controller keinen Strom mehr hat und die verschiedenen Methoden zum Aufladen.
2. Überprüfen Sie, ob das Gerät in einem dunklen Bereich schattiert ist.

3. Wechseln zu einer kabelgebundenen Verbindung.
4. Überprüfen Sie, ob das Gerät durch Hindernisse blockiert oder gestört werden. Sie können es an anderer Stelle oder zu anderen Zeiten erneut versuchen.

Lösungen für Drift
Wenn der Controller driftet, müssen Sie den Controller kalibrieren. Schritte: Klicken Sie auf „Einstellungen", klicken Sie auf „Controller und Sensoren" und klicken Sie auf „Steuerknüppel kalibrieren".

Über die somatosensorische Kalibrierung
Drücken Sie die Taste ⓡ3 " und halten Sie gleichzeitig die Taste ⓡ2 "-" gedrückt (Drücken Sie zuerst die Taste ⓡ3 " und dann die Taste ⓡ3 "HOME"). LED1 LED2 LED3 LED4 schalten sich ein.
Drücken Sie die Taste ⓡ3 " zu diesem Zeitpunkt schalten sich LED1 LED2 LED3 und LED4 gleichzeitig aus, um anzuzeigen, dass die Kalibrierung erfolgreich ist.

Lösungen für die Controller-Trennung
Der Grund dafür kann sein, dass der Controller keinen Strom mehr hat und die verschiedenen Methoden zum Aufladen.
2. Überprüfen Sie, ob das Gerät in einem dunklen Bereich schattiert ist.

3. Wechseln zu einer kabelgebundenen Verbindung.
4. Überprüfen Sie, ob das Gerät durch Hindernisse blockiert oder gestört werden. Sie können es an anderer Stelle oder zu anderen Zeiten erneut versuchen.

Lösungen für Drift
Wenn der Controller driftet, müssen Sie den Controller kalibrieren. Schritte: Klicken Sie auf „Einstellungen", klicken Sie auf „Controller und Sensoren" und klicken Sie auf „Steuerknüppel kalibrieren".

Wireless: Sie können PC-Spiele auf Steam spielen. Nicht alle PC-Spiele sind mit dem Controller kompatibel. Bitte überprüfen Sie vorhe, dass das Spiel den Controller unterstützt.

Für PC + Bluetooth-Modus
1. Drücken Sie gleichzeitig die Tasten ⓐ + ⓑ HOME für 2-3 SEKUNDEN, um den Controller einzuschalten (um ein versehentliches Berühren zu vermeiden, wird empfohlen, zuerst die ⓐ HOME-Taste zu drücken und festzuhalten, dann die Home-Taste zu drücken und festzuhalten, dass die zwei Tasten gleichzeitig länger als 3 Sekunden gedrückt gehalten werden).

2. Wenn LED2 und LED3 häufig blinken, wechselt der Controller in den Suchmodus.

Suchmodus ——— ● ● ●

3. Schalten Sie Bluetooth ein, gehen Sie in den Suchmodus und klicken Sie auf das Gerät, um nach dem Controller der N-Switch zu suchen, um eine Verbindung herzustellen.

4. Nach erfolgreicher Verbindung leuchten LED2 und LED3, was bedeutet, dass der Controller normal verwendet werden kann.

Verbindung erfolgreich ——— ● ● ●

Hinweis: Nicht alle Bluetooth-Spiele sind mit dem Controller kompatibel. Bitte vergewissern Sie sich, dass das Spiel den Controller unterstützt.

Für Kabelgebundenen Modus
1. Schließen Sie den Controller mit dem USB-Kabel an den Computer und den USB-Port des Hosts an, und die entsprechende LED-Leuchte des Controllers leuchtet langsam.

Verbindung erfolgreich ——— ● ● ●

2. Der Controller ist standardmäßig auf Input-Modus (Computermodus) auf der PC-Seite eingestellt, und die Tasten sind nicht XB0-Tastenlayout.

• Input-Modus kann zwischen Input und Direct umgeschaltet werden, ohne dass die Spieleinstellungen auf der Spieleplattform vorgenommen werden müssen.

3. Drücken und halten Sie die HOME-Taste für 3s, es kann von Input in den Direct-Modus（PC/360-Modus）umgewandelt werden. LED und LED1 waren gleichzeitig eingeschaltet.

• "Input" muss benutzerdefinierte Schaltflächen festlegen

Suchmodus ——— ● ● ●

3. Schalten Sie den blauen Zahn des Telefons ein, gehen Sie den Suchmodus ein und klicken Sie auf das Gerät, um nach dem Controller der N-Switch zu suchen, um eine Verbindung herzustellen.

4. Nach erfolgreicher Verbindung leuchten LED2 und LED3 eingeschaltet, was bedeutet, dass der Controller normal verwendet werden kann. Wenn Sie eine Verbindung mit einem anderen Gerät herstellen müssen, vergewissern Sie sich, dass das Spiel den Controller unterstützt.

Connection Successful ——— ● ● ●

Note: Not all PC games are compatible with controller, please confirm that the game supports controller before use.

About TURBO Function
There are 3 burst speeds and auto speeds(S shot/s, D shot/s, 25 shot/s).Default for first connection 12 shot/s.

S shot/s, The HOME light flashes in a moderate manner (slowly flash for 2 time per second).

D shot/s, The HOME light flashes frequently. (slowly flash for 4 times per second).

25 shot/s The HOME light flashes frequently. (slowly flash for 4 times per second).

2 types of bursts: manual burst and auto burst

1. Manual burst: Press and hold the ⓡ2 button, and then press the ⓨ button one of the function buttons to turn on the manual burst.

2. Open auto burst: Press and hold the ⓡ2 button, and then press and hold the button that has turned on the manual burst to turn on auto burst. (Auto burst can be paused).

3. Clear burst: Press and hold the ⓡ2 button, and then press and hold the button that has turned on the auto burst to turn off the current button with burst function.

4. Clear all burst button burst: Press and hold the ⓡ2 button and the ⓨ "Down" arrow on the D-pad. Once the controller vibrates, the burst function of all buttons is cleared.

Adjust the burst speed:

1.How to increase the burst speed?
Press and hold the ⓡ2 button and the △ "up" arrow on the D-pad. Once the controller vibrates, the burst speed is successfully increased.

2.How to reduce burst speed?
Press and hold the ⓡ2 button and the ▽ "Down" arrow on the D-pad. Once the controller vibrates, the burst speed is successfully reduced.

Snow to set the duration when adjusting the burst speed?

Press the ⓡ2 button and press the △ button/▽ "Down" arrow on the D-pad at the same time. Once the controller vibrates, the command is successfully set.

6. Will the burst setting be lost when the controller is disconnected. The controller will keep the last setting when it is connected.

About Vibration

There are 4 levels settings, is total: weak, none, medium, strong (Default strong, 0,33%, 66%, 100%).

How to set up the vibration?

Press the vibration ⓥ adjustment button at the back of the controller, and the controller will vibrate in 4 speeds in sequence.

Which speed is the default for the first connection?

Default strong (100%) vibration.

How to set the vibration to be turned off?

Set via the Mapping Mode.

M1 or M2 + "-": Only one button value can be mapped to the back button under the Mapping Mode.

M1 or M2 + "-": You can define up to 16 button values to the back buttons in macro definition mode.

* The default M1 and M2 have no button function value.

How to map one button to M1 or M2 key?

1.Press and hold M1 or M2 + "-" at the same time for 2-3 seconds. The LED flash frequency, and the RGB lights of the left and right joysticks turn white and flash slowly, indicating that it enters the programming mode.

2.Press a macro button button (A/B/X/Y/L1/L2/R1/R2/M1/M2) to be mapped, and the RGB lights of the left and right joysticks flash from slowly to fast, indicating that the function button to be mapped have been selected.

Example:
To map the four button values of A+B+X+Y to M1 key: press M1 + "-" at the same time for 2-3 seconds. Once the controller vibrates, the RGB lights of the left and right joysticks turn white and flash slowly, which means the controller already the mapping mode. Press the A, B, X, Y, buttons in turn, and then press the M1 key, the RGB lights of the joystick flash slowly to frequently, Press M1 to confirm, and the controller vibrates twice, indicating that the setting is successful.

How to clear the M1/M2 function that has been set?
Press "+" + buttons for 2 seconds. Once the controller vibrates, the setting is cleared and M1/M2 has no button function value added

Über die somatosensorische Kalibrierung
Drücken Sie die Taste ⓡ3 " und halten Sie gleichzeitig die Taste ⓡ2 "-" gedrückt (Drücken Sie zuerst die Taste ⓡ3 " und dann die Taste ⓡ3 "HOME"). LED1 LED2 LED3 LED4 schalten sich ein.
Drücken Sie die Taste ⓡ3 " zu diesem Zeitpunkt schalten sich LED1 LED2 LED3 und LED4 gleichzeitig aus, um anzuzeigen, dass die Kalibrierung erfolgreich ist.

Lösungen für die Controller-Trennung
Der Grund dafür kann sein, dass der Controller keinen Strom mehr hat und die verschiedenen Methoden zum Aufladen.
2. Überprüfen Sie, ob das Gerät in einem dunklen Bereich schattiert ist.

3. Wechseln zu einer kabelgebundenen Verbindung.
4. Überprüfen Sie, ob das Gerät durch Hindernisse blockiert oder gestört werden. Sie können es an anderer Stelle oder zu anderen Zeiten erneut versuchen.

Lösungen für Drift
Wenn der Controller driftet, müssen Sie den Controller kalib